



## LOADING INSTRUCTIONS

1. Open right-hand side of label holder (A).
2. Push label roll support (B) forward and insert labels.
3. Close label holder (A) and slide label strip down and out of bottom of machine.
4. Close and hold down platen (D) squeeze operation lever (C) repeatedly until 5 labels are fed out.
5. Remove protruding labels from backing paper.
6. Fold label strip back and in line with bottom cover (E) and close cover until it clicks.